

## SIMPLE INSTALLATION OF INDUSTRIAL GRADE HYDROPHOBIC QUIETFIBER®



1. Materials needed for QuietFiber install. Hot glue gun, scissors, fabric\*, serrated knife, measure



2. Use a serrated knife to cut QuietFiber material.



3. Center the QuietFiber material over fabric\* and apply the hot glue as desired.



4. Use hot glue on mounting under cabinets, etc.



5. QuietFiber pillow shown in fabric under a bar.



6. QuietFiber pillow shown in fabric hot glued under a bar stool.



7. QuietFiber behind a tapestry.



8. QuietFiber pillow on top of a china cabinet



9. QuietFiber hung from ceiling beams, in a gymnasium.

\* Be sure you can blow air through the fabric to insure acoustical transparency.